



Read Instructions fully before installing your blind.

Item Checklist

- Track & Control Wands
- Panels & Base Rails
- Brackets & Screws

Tools you will need

- Cordless Drill with Philips head drill bit
- Metal Tape Measure
- A Ladder if necessary

It is important to securely attach the brackets to the mounting surface. To achieve this, the included screws must secure into wood studs, otherwise a fastener is required for secure mounting (not included) Make sure the fastener you purchase is suitable for the weight of the product.

Plaster:	Timber:	Concrete, Stone, Brick or Tile:
We recommend the use of Ramset 10mm Grip Hollow Wall Anchor	Pre-drill holes and use the included screws.	Use a masonry drill and appropriate plugs, anchors or screws.

Make sure hands are clean before handling fabric panels. Remove product from packaging and lay out at each window.

Step 1. Positioning the Brackets

Space the brackets evenly across the window. Keeping the end brackets approximately 50mm in from the edge of the architrave .

Place a mark with your pencil at the screw points. Place one screw in the back plate of the bracket and fasten with a drill or screwdriver, repeat for the second hole. Repeat for all brackets.

Step 2. Positioning the Track

Lift the track into place with the Velcro facing forward.

- Hook the back of the bracket into the groove on the topside of the track.
- Lift the front of track up and lock into place in the bracket.

Making sure to hear it click and secure in position, before releasing the track.

Step 3. Attaching Base Rails & Hanging Panels



Lay the panel on a flat clean surface to attach the base rails. Take each base rail and remove the hex screws with the hex key. Take out the plastic spline and remove the paper off the adhesive backing.

Stick the spline to the base of the fabric. Slide the base rail onto the spline and fasten the screws. Simply Velcro each panel into place by attaching it flush with the top of each slider. Each slider can be easily unclipped from the next slider to give easy access for attaching each panel.



Step 4. To Operate

Hook the wand to each end of the tracks to enable easy operation from either end. To open and close, slowly push or pull the wand in the direction that is required.

Make sure not to operate too fast or you will risk damaging the panels.

Adjusting the drop for Blinds Today Panels

If you require a shorter drop, each panel can easily be trimmed to size.

1. Lay the panel on a flat clean surface. Using a tape measure mark your panel at the base, to the desired finished drop, less 25mm to allow for the track. E.g.. You require a drop of 2200, measure & mark at 2175
2. Draw a straight line across the base and cut along the line with sharp scissors or a Stanley knife.
3. Attach the base rail as described in Step 3 above.