



Installing the brackets

1




Installing the blind

2



Adjusting the tension



3




Over time the cords may slacken off and require re-tensioning. You'll know if the blind needs re-tensioning as it will begin to slip back down of its own accord when raised.

Start by removing the bottom rail - to do this, slide it upwards from one corner, to slide the bracket out from under the seal.

Then, remove the brackets from both ends of the rail and put the rail to one side.



Slot the brackets back into the corners, as per step 1 of this guide.



At the bottom of the blind the cord is connected to both ends of a small spring. Untie the knot at one side of the spring.

Pull the end of the cord through by 5-10mm, then give the blind a test to see if the tension is right. Repeat this as necessary until the tension is correct.

Once you're done, simply click the bottom rail back into place as per step 2 of this guide.