





## Handy Hints & Trouble Shooting

- If your blind is hard to operate or making a clunking noise and not rolling smoothly, it is likely that the positioning of the chain drive end of the blind, is in the incorrect position in the bracket. Please go back to the "Positioning of the Blind" section of the instructions and make sure that the end cap has not been slightly rotated out of position. The Map of Australia logo should always be in the 12 o'clock position.
- For large blinds, have another person help you hold the blind, whilst placing it into the brackets
- From time to time a blind can track off to one side, making it hard to wind up and risk the cloth being damaged. This can easily be remedied by unrolling the blind and placing a 10cm piece of masking tape onto the aluminium tube on the side you want the blind to go to. Add a couple more thicknesses until the blind rolls up straight. If this does not fix the problem please contact us.
- To maintain furniture and
- Cleaning the you may da too hard when cleaning as
- If the blind over time. and this should fall out
- Blinds left in a curve /kin g a memory and holding larly to avoi to different heights regu-
- If you decid dered, simp to what you have or- positions ov eed to swap the bracket
- If you need have remov from the tube once you Slightly loos e of the chain drive. Once you h will drop into the tube. the chain fr ough for you to release place. lot the end cap back in



Blindsonline proudly offer an extensive 5 year warranty on your new blinds.

Full warranty details are located at our website.

For further information please contact our customer service team Monday to Friday 9am to 5pm

**Phone:** 1300 761 179 or **Email:** sales@blindsonline.com.au

**Choose. Measure. Order. Install. Easy.**